ROSE

A

LATCH LOCKING
CAM

CAM KEYWAY MUST
FACE TOWARD HINGE
EDGE OF THE DOOR

DETAIL A

1. USING A SCREWDRIVER, ROTATE THE CAM
   UNTIL THE KEYWAY FACES TOWARDS THE
   HINGE EDGE OF THE DOOR AS SHOWN IN
   DETAIL "A".
2. INSERT THE KEY INTO THE CYLINDER AND
   ROTATE THE TAILPIECE CLOCKWISE 90
   DEGREES.
3. MAKING SURE THAT THE TAILPIECE ALIGNS
   WITH THE LOCKING CAM, INSTALL THE LEVER
   ONTO THE LOCKBODY SHAFT UNTIL IT SNAPS
   INTO PLACE.

REV 1