

### **ROLLER STOPS**



# **271W**Roller Bumper

Certification: Meets ANSI A156.16 for L02193

Base Diameter: 2" (51 mm)
Projection: 4-1/2" (114 mm)


Materials: Cast brass with grey rubber roller Finishes: US3, US10, US10B, US26, US26D

Fasteners: Three (3) #10 x 1" FPHWS and three (3) plastic anchors

Notes: • For use when two doors swing into each other at right angles

(back to back)

• Prevents damage to the door and door hardware





## 272W Roller Bumper

Certification: Meets ANSI A156.16 for L02193

Base Diameter: 2" (51 mm)r Projection: 6-1/4" (159 mm)


Materials: Cast brass with grey rubber roller Finishes: US3, US10, US10B, US26, US26D

Fasteners: Three (3) #10 x 1" FPHWS, and three (3) plastic anchors

Notes: • For use when two doors swing into each other at right angles

(back to back)

• Prevents damage to the door and door hardware





## 273W

#### **Curved Roller Bumper**

Certification: Meets ANSI A156.16 for L12213

Projection: 2-21/32" (67 mm)

Materials: Cast brass with grey rubber roller Finishes: US3, US4, US10, US10B, US26, US26D

Fasteners: Three (3)  $\#10 \times 1''$  FPHWS and three (3) plastic anchors Notes: • Used when two doors swing into each other at odd angles

• Prevents damage to the door and door hardware

